

1. PRODUCT NAME

Curb Overlay & Full Foam Curbs

2. MANUFACTURER

PROFLEX® Products, Inc.
1603 Grove Ave
Haines City, FL 33844
Telephone: 863-937-9623
Toll Free: 877-577-6353
Fax: 863-937-9624
Internet: www.proflex.us

3. PRODUCT DESCRIPTION

PROFLEX® Curb Overlays & Full Foam Curbs are made from high-density expanded polystyrene wrapped with a fiberglass mesh and liquid waterproof membrane finish. Curbs are lightweight and ready-to-tile.

Materials Required (Curb Overlays)

- Utility knife
- Latex modified thinset mortar
- Large headed fastener
- Polyurethane sealant

Materials Required (Full Foam Curbs)

- Utility knife or fine tooth saw
- Latex modified thinset mortar
- Polyurethane sealant

4. TECHNICAL DATA

N/A.

5. INSTALLATION

Preparatory Work

Ensure substrate is level and flat prior to beginning

Installation of Curb Overlay

NOTE: Curb Overlay should be installed before installation of mortar bed and after installation of waterproof membrane.

1. Cut Curb Overlay to dimension of opening.
2. Coat inside of Curb Overlay with latex modified thinset mortar and place over pan liner.
3. Ensure that Curb Overlay is set firmly against curb structure.
4. After leveling Curb Overlay, secure with large headed fastener on outside of curb structure. Do not compromise inside of curb structure with fasteners.
5. Apply a bead of polyurethane sealant where Curb Overlay meets the wall/jamb.
6. Install tile according to Tile Council of North America (TCNA) guidelines.

Installation of PreFormed Full Foam Curb

1. Cut Full Foam Curb to dimension of opening.
2. Apply latex modified thinset mortar to floor area.
3. Apply latex modified thinset mortar to bottom and both ends of the curb.
4. Embed curb into thinset mortar and apply weight to curb to properly seat curb into wet thinset.
5. Allow thinset to cure according to manufacturer's instructions.
6. Caulk with polyurethane sealant where curb meets wall/jamb.
7. Install shower pan per manufacturer's instructions and TCNA guidelines.
8. Extend waterproofing membrane up and over curb.
9. Install tile according to Tile Council of North America (TCNA) guidelines.

6. AVAILABILITY

PROFLEX® Products are available nationwide.

To locate PROFLEX® products in your area, please contact:

Phone: 877-577-6353

Website: www.proflex.us

7. WARRANTY

PROFLEX® Products, Inc. offers a limited warranty for this product when used in accordance with printed specifications. A copy of the limited warranty can be obtained by calling technical services at 877-577-6353 or visiting www.proflex.us

*PreFormed Curb Overlays and Full Foam Curb warranty will be voided if modified on the jobsite other than for cutting product to proper length. Waterproofing should not be compromised. PreFormed Ready-to-Tile Components must be installed per Manufacturer's Instructions.

8. MAINTENANCE

None required.

9. TECHNICAL SERVICES

Technical assistance

Information is available by calling the Technical Support

Toll Free: 877-577-6353

Fax: 863-937-9624

Technical and safety literature: To acquire technical and safety literature, please visit our website www.proflex.us

10. FILING SYSTEM

Division 9